



Ref #	Part Number	Description	Qty
1	00-0503	Screw(Left Thread)	1
2	517-001B	Keyless Chuck(3/8")	1
3	600R-031	Chuck Washer	1
4	615R-002	Clamp Nut	1
5	00-2338	Ball Bearing	2
6	616R-015	Idler Gear Housing A	1
7	616R-018	Gear Cage B	1
8	00-3413	Pin	3
9	616R-014	Idler Gear	2
10	616R-005	Front End Plate	1
11	00-2347	Ball Bearing	1
12	615R-009	End Plate	1
13	600R-006	Cylinder	1
14	600R-022	Pin	1
15	616R-007	Rotor	1
16	600R-008	Rotor Blade	5
17	600R-020	Motor Gasket	1
18	615R-001	Motor Housing	1
19	00-0605	Trigger Screw	1
20	615R-025	Trigger	1

Ref #	Part Number	Description	Qty.
21	615R-026	Spring	1
22	615R-021	Reverse Knob	1
23	00-41193	O-Ring	1
24	615R-035	Valve Stem	1
25	00-4190	O-Ring	1
26	00-41157	O-Ring	1
27	00-4121	O-Ring	2
28B	615R-024-B	Valve Sleeve	1
29	00-3456	Pin	1
30	00-3308	Spring Pin	1
31	243H-021	Exhaust Deflector	1
32	00-4126	O-Ring	1
33	00-4127	O-Ring	1
34	00-4143	O-Ring	1
35	00-2332	Ball Bearing	1
36	615R-023C	Air Inlet(1/4"NPT)	1
37	615R-019B	Muffler Tube	1
38	615R-036	Muffler	1
39	615R-037	Muffler	2
40	00-3903	Hex. Wrench	1